BULK METALLIC GLASS

A force of our time.

Overview



Which materials can offer...

- The yield strength of high end steels
- The elasticity of plastics
- Corrosion resistance like precious metals
- The possibility to cast finished polished surfaces in one step




Bulk Metallic Glasses



Overview

- **Bulk Metallic Glass (Amorphous Metals)**
- **Alloy Properties**
- **Mechanical Properties**
- Chemical behavior
- **Applications**
- Production
- **Summary**






FACE CENTERED CUBIC STRUCTURE (FCC)


Atoms touch each other along face diagonals.


--Note: All atoms are identical; the face-centered atoms are shaded differently only for ease of viewing.

ex: Al, Cu, Au, Pb, Ni, Pt, Ag

- Coordination #= 12







4 atoms/unit cell: (6 face x 1/2) + (8 corners x 1/8)



Atomic Radii and Crystal Structures for 16 Metals

Metal	Crystal Structure ^a	Atomic Radius ^b	Metal	Crystal Structure ^a	Atomic Radius ^b
Aluminum	FCC	0.1431	Molybdenum	ВСС	0.1363
Cadmium	НСР	0.1490	Nickel	FCC	0.1246
Chromium	ВСС	0.1249	Platinum	FCC	0.1387
Cobalt	НСР	0.1253	Silver	FCC	0.1445
Copper	FCC	0.1278	Tantalum	ВСС	0.1430
Gold	FCC	0.1442	Titanium (α)	НСР	0.1445
Iron (α)	ВСС	0.1241	Tungsten	ВСС	0.1371
Lead	FCC	0.1750	Zinc	НСР	0.1332


^b A nanometer (nm) equals 10⁻⁹m; to convert from nanometers to angstrom units (Å), multiply the nanometer value by 10




^a FCC = face-centered cubic; HCP = hexagonal close-paked; BCC = body-centered cubic

Structure Matters

Amorphous Metals





Most Metals


- Polycrystalline grains of varying shapes and sizes.
- Misaligned planes of atoms slip past each other easily, absorbing energy and allowing dislocations to move, making deformation permanent.
- Grain boundaries represent weak spots


Metallic Glass

- Cooled faster than atoms can rearrange into a crystal
- Dislocation movement obstructed so absorbs less energy and rebounds elastically to its initial shape
 - Resistant to corrosion and wear
 - Slow heat conduction limits casting




Vit1B Structure







BMG Time Vs. Temperature





Time

Bulk Metallic Glass

Vit I b:

- $\bullet Zr_{67}Cu_{10.6}Ni_{9.8}Ti_{8.8}Be_{3.8}$
- large temp. window

Vit601:

Zr_{62.5}Cu₃₁ Ni_{3.2}Al_{3.3}Be_{0.1}

<u>Vit105</u>:

- $\bullet Zr^*_{65.7}Cu_{15.6}Ni_{11.8}Al_{3.7}Ti_{3.3}$
- •

Vit I 06a:

 $\bullet Zr^*_{70.1}Cu_{13}Ni_{9.9}Al_{3.6}Nb_{3.4}$

Additional alloys:

GMT: $Ni_{76}Cr_{8.5}Nb_{5.2}P_{9.4}B_{0.6}Si_{0.3}$

Pt850: $Pt_{85.24}Cu_{7.1}Ni_{2.36}P_{5.3}$ JPL: $Ti_{43}Zr_{41}Cu_7Al_3Be_6$







Figure 1. Cooling rates required to achieve an amorphous microstructure in various materials.




BMG Product Placement





Extraordinary elasticity for metals


Elasticity =
$$\frac{Re}{EMod}$$





Resilience

Energy that can be absorbed per volume before plastic deformation.




$$U_r = \frac{1}{2}\sigma_y \varepsilon_y = \frac{\sigma_y^2}{2E}$$

Alloy	YA MPa	E-Modul GPa	U _{RV} =1/2(Y _s ^2/E) MPa
<u>Vit105</u>	1524	93	12.5
<u>Federstahl</u> <u>1.7176</u>	1250	210	3.7
Ti-6Al-4V	880	128	3.0
7075 Aluminium	503	73	1.7



Characteristic properties of Bulk Metallic Glasses

- Complex shaping "in one step"
- Elasticity/spring properties
- High Strength(~ 1500 MPa)
- Tight tolerances (like CNC)
- High reflectivity (polishes surfaces)
- High Hardness (53 HRC)
- Corrosion resistance
- Bio compatibility
- CNC machining possible





Mechanical properties of Vit105

Yield Strength Re ~ Rm	1524 MPa
Young's Modulus	93 GPa
Elasticity	~ 1,80 %
Hardness	53 HRC
Fatigue limit at 10 ⁷ cycles	304 MPa
Fracture Toughness K1C	~ 40 Mpa m^1/2
Poisson's	0,38



Physical properties of Vit105

Density	6.57 g/cm³
Heat capacity	329 J/kg K
Heat Volume	2161 kJ/m³K
Thermal Expansion	12 μm/mK
Electric Resistance	160 μOhm cm
Glas Transition Temperature	399°C
Crystalisation Temperature	468°C
Operating Temperature	≤250°C
non magnetic	μd = 0,999991



Zr BMG Properties

Alloys	Vit 1b	Vit 601	Vit 105	Vit 106a
Yield Strength	1800	1795	1850	1800
MPa (ksi)	(261)	(260)	(268)	(261)
Elastic Modulus	95	91		95
GPa (10 ⁶ psi)	(13.8)	(13.3)		(13.8)
Fracture Toughness	55	70	75	30
MPa√m (ksi√in)	(50.0)	(63.7)	(68.3)	(27.3)
Density	6.0	6.9	6.6	6.7
g/cc (lbs./in ³)	(0.217)	(0.249)	(0.238)	(.242)
Glass Transition (Tg)	352	420	403	395
C (F)	(665)	(788)	(757)	(743)
Crystallization (Tx)	466	495	469	499
C (F)	(871)	(923)	(876)	(930)
Melt Temp (Tm)	644	753	805	837
C (F)	(1191)	(1387)	(1481)	(1539)



Storyline of BMG

- Since the 90's Materion is supplier for Liquidmetal®
- 2010: Liquidmetal® contacts Materion to supply the finished alloys
- 2015: Engel introduces metal injections molding machine "-e-motion 100"
- 2018: Eutectix replace Materion in producing and promoting BMG
- 2019: Engel introduces new metal injections molding machine "Victory 120"
- 2019: RS Acciai become official reseller in european market about BMG
- 2020: Eutectix agreement with Liquidmetal®













Bulk Metallic Glass Supply Chain



Materion VIM unit (Elmore, OH) Materion



BMG Alloy Feedstock Materion/Engel










Vacuum Injection Molding

- Producer




BMG Injection Molding Machine













Rapid Discharge Forming Process

- ▶ Input Material
 - ▶ 5mm Dia. Rods
 - ▶ 8mm Dia. Rods
 - Length determined by part to mfg
- ▶ High Product Yield
- Recycle of alloy? Yes, material can be cleaned and recycled?











Bulk Metallic Glass – What else is special?



Small scale extrusions



Rapid Discharge Forming



Springs and Gears

Ease of processing

- Thermoplastic forming
- Rapid discharge forming
- Injection molding
- Die casting



Blow Molding




Golden et al., Adv Mater, 23, 461 (2011)

Injection Molding Guidelines

DESIGN CHARACTERISTICS

Here are a few basic guidelines for identifying candidate Liquidmetal parts:

- Part weight up to 80 grams (100 grams maximum total shot size of which 80 grams is usable)
- Maximum dimension of 100mm
- Outer draft angles of 0.5° to 3°
- Inner draft angles of 1° to 5°
- Wall thickness 0.6mm to 4.0mm
- Dimensional tolerances of ±.025 mm for critical dimensions
- Production volumes from tens of thousands to millions of parts





Injection Molding Production Tolerance

	BMG	CNC	MIM
Tolerance	± 8 μm	±8 μm	± 75 – 125 μm

	Form		Toleranzen	
	Function given part, linear shape Standard tolerance, linear shape		±0.02 per 25.4 mm	
			±0.05 mm	
	Flatness		0.05 mm	
	Straightness	_	0.05 mm	
	Angle	_	0.001 mm	
	Concentricity		0.05 mm	DIMENSIONAL ACCURACY With the application of manufacturing p the Liquidmetal* process can achieve dir
	Roundness	0	0.05 mm	results that are usually only common to p Numerical Control) machining processes accomplishes these results at much lowe



With the application of manufacturing process simulation and analysis tools, the Liquidmetal* process can achieve dimensional accuracy and repeatability results that are usually only common to production CNC (Computer Numerical Control) machining processes. But the Liquidmetal process accomplishes these results at much lower costs than machining. Today, designers can expect dimensional accuracy and repeatability of $\pm 0.075\%$ of a given part dimension. Of course, recognition of mold fabrication tolerance capabilities, especially on high cavitation molds, needs to be considered before committing part specifications. Liquidmetal alloys solidify during the molding process nearly isotropically, so design sensitivities to the 0.4% solidification shrinkage of the material and dimensional tolerances of



Chemical Properties of Vit 105



- Salt Spray Test according to ASTM B117 no signs of corrosion
- Resistant to acids and bases
- High corrosion and wear resistance
- Passed various biocompatibility tests: Toxicity, Irritation, Sensitization, Systemic Toxicity, Hemocompatibility, Mutagenicity, Pyrogenicity



BMG – Production History Overview



VIIC Furnace (VC9)



Casting mold (weight = 600kg)

Scaled production:

- Scaled from batches of 10 and 30 kg
- Currently batches of ~85 kg
- Alloyed and cast under vacuum



Crucible charged for alloying



BMG - Production History Overview



Mold, alloyed rods partially removed

Scaled production

- Each batch is cast into rods
- Rods are separated from the reusable casting material
- Finished rods are sold as complete rods or cut to length



Complete rods removed from the mold



Bulk Metallic Glass Markets





Consumer Electronics (CE)



Watches and Luxury Goods



Aerospace/Defense

Biomedical

Oil and Gas

Performance Automotive



Industrial Components



Sporting Equipment



BMG Gears - NASA





BMG Gears



Bulk Metallic Glass (BMG) Gears



- ➤ BMG Gears is developing dry lubricated and non-lubricated planetary and strain wave gearboxes fabricated from new bulk metallic glass alloys for power constrained cryogenic environments.
- ➤ The technology enables mechanisms to function in cryogenic environments, such as on the surface of Europa, without having to use heaters thus allowing more science return for the available power.







BMG Gears



BMG Gears - Motivation



- Future NASA missions, such as landing on and investigating the surface of Europa where the temperature is below -170 °C, will be very power constrained.
- The use of power hungry heaters to allow mechanism like robotic sampling arms to function will reduce the mission lifetime and decrease the science return.
- Newly developed BMG alloys for planetary and strain wave gearboxes enable them to function with dry lubricants or even unlubricated, thereby requiring no electrical power for heaters to operate, reduced system complexity, and increased mission lifetime/science return.




BMG Gears



Planetary Gearbox Development




BMGs considered for combination of hardness, toughness, modulus





Pin-on-disk and spur gear testing used to screen potential alloys and down-select for gearbox component fabrication and testing.



One step casting of gears





Proof of concept demonstrated in hybrid steel/BMG gearbox (MoS₂ dry lubricated BMG planet gears) tested to Mars Rover conditions.

Next steps: Fab and test custom 3-stage planetary gearbox to Europa conditions.

